After caught by "RUNDER", and gone to the uppest place, Person come to "MUTANTER".

In case that the Person was caught by "RUNDER", the "SHOT" and "SMART" can rescue the "PERSON".

When "RUNDER" was hitted by "SHOT" or "SMART", "PERSON" fall down and down, however, the ROCKET can rescue the "PERSON" in over 4 lines from the bottom, and the ROCKET pick up "PERSON", take the falling Person to the ground safely.


In case of under 4 lines, the "PERSON" will be die.

: to display the position of "PERSON", "RUNDER", "MUTANTER"


without PLAY-AREA.

The speed for "RUNDER" and "MUTANTER" is accelerated in every

"CLEAR".



DEFENDER



7

POWER SOURCE

SCORE

GAME END

GAME

SCANNER

SPEED

: Can display 4 DIGITS.

Each points are:

1) Destroying "RUNDER" 10 points 2) Destroying "MUTANTER" 15 points

3) Rescuing the "PERSONS" who is caught by "RUNDER"

50 points 4) And taking the Persons to Ground 50 points 20 points

5) Arrived safely on Ground

6) Cleared all "RUNDER", "MUTANTER" Remained persons X 10 points

Every time you score 1,000 points, you get an extra "ROCKET" as

But if you already have 4 ROCKET'S in reserve, you can't get any


: When all ROCKET'S were destroyed, the GAME come to "END" and "STOPPED".

DEMONSTRATION: In "FULL AUTO" the ROCKET move up and down automatically, also ACCEL and FIRE move automatically.

Can operate "KEY" for "REVERSE", "SMART" and "WARP".


See to "FIRE-KEY" section.


www.handheldmuseum.com



- When dry batteries are used:
- 1. Set ON/OFF switch to "OFF".
- 2. Remove the lid of the battery case on the back side of the body by pusing it in the arrow-mark direction.
- 3. Put 4 UM-2 (size "C") dry batteries in place confirming the position of their + - polarities in the case,
- 4. For closing the lid set both ends of the fid in the grooves on the body and slide the lid in the arrow-mark direction.
- When AC adaptor is used:
- 1. Buy the AC adaptor at the shop where you bought,
- 2. Turn off the switch, and then insert the plug of AC adaptor into the jack on the top of the body.
- 3. Insert the AC adaptor into your household plug consent.
- Ratings of AC adaptor used:
- 1. Input power source voltage: AC100V. 50Hz, 60Hz.
- 2. Output voltage: DC 6V.
- 3. Load current: 300 mA.
- 4. Plug diameter: 2.5 mm.
- 5. + -: The inside is + and the outside is -.

NAME OF PARTS





"HOW TO OPERATE" for "DEFENDER"

SUMMARY

Move your "ROCKET" with the control stick to avoid the Chasing Bomb, the RUNDER, and the MUTANTER.

Score points when you destroy the RUNDER and the MUTANTER or blow up the MISSILE and BOMB button, and the ROCKET pick up the PERSON take the falling PERSON to the ground safely.

HOW TO PLAY

1. Turn the SOUND/POWER switch to "SOUND ON" or "SOUND OFF".

*When the SOUND/POWER switch is turned to "SOUND OFF", the game tone will not sound.

2. KEYS FUNCTION

to make the ROCKET move for Upper-direction at the stabilized speed, Up-KEY

to the highest place.

DOWN-KEY to make the ROCKET move for Lower-direction at the stabilized speed,

to the lowest place.

REVERSE-KEY: to make the ROCKET'S direction reverse.

to accelerate the ROCKET forward ACCEL-KEY

(This mean the other move without the ROCKET'S moving)

FIRE-KEY : to fire the shot from the ROCKET.

Can't fire the next shot till the first shot disappeard.

*(If keep pushing when electric source is putted "ON" automatically

checked with FL and come to "FULL-AUTO".)

to destroy all "RUNDER" and "MUTANTER" within "PLAY-AREA" SMART-KEY

to make the ROCKET move to other place in an instant. WARP-KEY

3. FUNCTION

PERSON

: When initition, one ROCKET appear at the left edge of fifth line from ROCKET

the bottom.

: to destroy "PERSON", "RUNDER" and "MUTANTER" SHOT

When the ROCKET placed at left, the ROCKET move to right.

When the ROCKET placed at right, the ROCKET move to left.

 to move rundom. RUNDER

If "RUNDER" find the Person, "RUNDER" try to catch the Person by

After catching the Person, "RUNDER" move up and become "MUTAN-

TER".

to fire the chasing bomb.

MUTANTER to move in closing to ROCKET.

to fire chasing bomb.

CHASING BOMB: to move forward at stabilized speed.

If hitted to ROCKET, can destroy the ROCKET. · When initiation, there are 10 Persons in bottom line.

- - : GROUND OR BOTTOM LINE

: ROCKET

MUTANTER

RUNDER

: PERSON

■ : CHASING BOMB MISSILE OR FIRE : REMANING ROCKETS

: REMANING SMART BOMBS